

Product Name: **XCDLWP5CT**


The products listed contains a light source of energy efficiency class:




XCDLWP5CT

Disassembly Instructions:

1. Ensure power is off prior to disassembly.
2. Slowly pull down until retaining clips are exposed then pinch together to remove with ease.
3. Unscrew and disconnect connector cables.
4. Undo terminations.
5. Unscrew screws on back of downlight.
6. Unscrew all visible screws and nuts to segregate all component parts.



Non replaceable light source



Non - replaceable control gear