

Product Name: **NON CORROSIVE**

The products listed contains a light source of energy efficiency class:



XCNC 14HENW




XCNC 14 / 15 / 24 / 26 NW / 15 / 16HENW



XCNC 16 / 25 NW

Disassembly Instructions:

1. Ensure power is off prior to disassembly.
2. Open buckle latches and remove diffuser.
3. Rotate the retaining clip to release gear tray
4. Undo terminations.
5. Remove screws mounting body to surface.
6. Unscrew all visible screws and nuts to segregate all component parts.



Replaceable light source by a professional



Replaceable control gear by a professional
